

EMPOWERING OUR WORLD
WITH CLEAN ENERGY



INSTALLATION MANUAL NAVODILA ZA NAMESTITEV

Balcony Easy Solar Bracket
Preprost solarni nosilec za balkon



1. Installation tools

1. Werkzeuge für die Installation



Allen wrench
Inbus ključ
(M8-M12)



Tape
Merilni trak



Twist Wrench
Momentni ključ
(M8-M12)



Wood Hammer
leseno kladivo



Electric Screw Machine
Električni izvijač



13mm Spanner
13 ključ

2. System components

2. Komponenten des Systems

(Accessories are subject to the actual product)
(Dodatki so odvisni od dejanskega izdelka)

x 2




x 2




x 3




x 2




x 2





x 2



x 2



Product specification Specifikacija izdelka

			
260mm	275mm	300mm	38mm
AI 6005-T5 AlMgSi0.5	AI 6005-T5 AlMgSi0.5	AI 6005-T5 AlMgSi0.5	SUS304 1.4301
			
35mm	35mm	40mm	
AI 6005-T5 & EPDM	AI 6005-T5 AlMgSi0.5	AI 6005-T5 AlMgSi0.5	
			
30mm	220mm	M8*20	M8*25
AI 6005-T5 AlMgSi0.5	AI 6005-T5 AlMgSi0.5	SUS304 1.4301	SUS304 1.4301
			
M8*55	M8*60	M8*90	
SUS304 1.4301	SUS304 1.4301	SUS304 1.4301	

3.Application scenarios

3 namestitev/ scenarij



Fixed on balcony with 0°



Fixed on balcony with adjustable tilt between 15°-30°;

Diagram pritrditve kavljev na balkonu pod kotom 0

Shema pritrditve kljuke na balkonu z nastavljivo Nagib med 15°-30°

4.Installation Instruction

4.Navodila za namestitev

4.1 Fixed on balcony with adjustable tilt between 15°-30°

4.1 Shema pritrditve kljuke na balkonu z nastavljivo Nagib med 15°-30°

4.11 Balcony Hook installation: Hooks are attached via bolts and holes in the panel frame

4.11 Montaža s kljukami na balkon: Kljuke se namestijo z vijaki in Stekla, pritrjena na okvir modula.



4.12 The hook and railing connection:the hook hangs on the balcony railing, through the bolt to prevent it from falling out;


4.12 Kljuka in balkonska ograja: Kavelj se obesi na balkonsko ograjo in vijak je napeljan tako, da ne more izpasti;







4.13 Rail installation: The bolt head snaps into the groove of the rail, the aluminum plate is on the other side of the railing, and the bolt is locked as shown in the picture;

4.13 Namestitev zajeralne tirkice: Vstavite glavo vijaka v samo
Vstavite vodilo, aluminijasta plošča je na drugi strani ograje, in pritrdite vijak, kot je
prikazano na sliki;



4.14 Installation of telescopic rod: The telescopic rod is pre-installed at the factory,
and the base is also locked on the rail with M8 bolts;


4.14 Namestitev teleskopske palice: Teleskopska palica je tovarniško vnaprej
sestavljena.
Počnute je prav tako pritrjeno na vodilo z vijaki M8;





4.15 L foot installation and connection: The L foot is locked on the other side of the panel frame with bolts, and then connected with the telescopic rod with bolts;

4.15 Namestitev L-noge: pritrdite L-nogo na drugo stran okvirja modula z vijaki, nato pa ga pritrdite s teleskopsko palico s sorniki;



4.16 According to the required angle, adjust the position of the telescopic rod and then lock the bolt, and the installation is completed;

4.16 Nastavite položaj teleskopske palice na želeni kot, povlecite privijte vijak in dokončajte namestitev




4.2 Balcony hook without angle solution

4.2 Diagram pritrditve kavljev na balkonu s kotom 0°

4.21 The hooks and rails are attached to the railing in the same way as the angled ones, removing the adjustable feet and L connectors. Press the panel directly on the guide rail with end clamps, as shown in the picture below. The M8 bolt head is snapped into the slot, and the nut is locked.

4.21 Način med kavljem, vodilom in ograjo je enak

kot s kotom. Odstranite nastavljivo nogo in L-prikljuek ter pritisnite modul neposredno na vodilo s stranskim pritiskom, kot je prikazano na naslednji sliki; Priprnite glavo vijaka M8 v rezo in pritrdite matico



4.22 The installation is completed

4.22 Namestitev je končana

